

**JOINTS WITH SOLID STEEL FLOATING FLANGES**  
**METRASPHERE™, DOUBLESPHERE™CABLESPHERE™ AND DOUBLE CABLESPHERE™**  
**OPERATION, INSTALLATION AND MAINTENANCE INSTRUCTIONS**

**General:** The Metrasphere family of joints (Metrosphere, Doublesphere, Cablesphere and Double Cablesphere) are elastomeric expansion joints designed to isolate vibration, absorb thermal expansion, and allow for minor pipe misalignment. Elastomeric expansion joints are available in a wide range configurations and elastomers; consult specific joint data for joint characteristics.

**Application:**

- 1 These joints are designed for use with standard IPS pipe flat or standard raised face steel flanges. Consult Metraflex if the Metrasphere is to be used with pipe and fittings made to other dimensions. Do not bolt directly to another component with an elastomer face.
- 2 Grooved Flange Adapter: If you must bolt directly to a Victaulic ® flange you must use a Metrasphere Transition Flange from Metraflex or equal.
- 3 Plastic Pipe Flanges: Metraspheres have a bead seal and may not be suitable for connection to plastic piping flanges such as PVC and fiberglass that require flat faced flange connection. Other Metraflex products are more suitable for this application, consult with Metraflex for details.
- 4 Check Valves: When connecting to any center guided style silent check valve, only install Metrasphere on the discharge side.

**Joint Preparation**

- 1 Before installation check the interior, exterior and flange faces of the expansion joint for cuts or gouges.
- 2 Care must be used when pushing the joint into the breech between the mating flanges so as not to roll the leading edge of the joint out of its flange groove.
- 3 It is acceptable (but not necessary) to lubricate the expansion joint flanges with a thin film of graphite dispersed in glycerin or water to ease installation and disassembly at a later time.

**INSTALLATION:**

- 1 Install at face to face dimension shown on drawing/catalog. Installation at different lengths or between flanges that are not parallel can lead to failure. Under no circumstance are flange bolts to be used to stretch the sphere into contact with a mating flange. Installation tolerance for overall length and misalignment is 1/8"
- 2 **DO NOT** use gaskets between the sphere and the flange surface.
- 3 If bolt threads are facing the joint, trim the length of the bolts so they do not extend past the nut more than 1/8" to avoid contact with the joint.
- 4 Using plated steel washers between the nut and the flange is recommended.
- 5 **Bolt Torque.** Use a torque wrench and the criss-cross method to apply torque to the nuts. First, uniformly torque the nuts to approximately 60% of the minimum torque. Ensure that the gap between the flanges is even around the flange. Then complete the tightening process. The gap between the flanges must be uniform when finished. **Minimum recommended flange bolt torque for the following joint sizes is: 1" to 2" – 45 ft-lb, 2-1/2" to 8" - 60 ft-lb, 10" to 20" – 80 ft lb. Do not over tighten to the point where there is metal to metal contact between the joint flange and the mating flange. NOTE – Rubber tends to relax after initial tightening, so it is necessary to retighten the flange bolts 24 hours after initial installation to the recommended torque.**
- 6 Control Rods: The use of control rods on Metrasphere is recommended for installations where the piping on both sides of the sphere is not properly anchored. Control rods are to be adjusted to allow movement that is less than or equal to the recommended extension. If the sphere is subject to compression the control rods must have additional nuts or compression sleeve installed to prevent over-compression.  
If you have purchased Cablesphere or Double Cablesphere, your joint has factory installed control cables and no other provisions for overextension are needed. If over compression is a possibility, control rods with limit stops are still needed.
- 7 Do not paint or insulate the joint, except when Hypalon is applied as a UV protectant.

**Testing:** Joint may be one-time pressure tested to 1-1/2 times the product's maximum operating pressure. Do not exceed maximum pressure or temperature during operation.

**Storage:** Ideal storage is a warehouse with a relatively dry, cool location. Store flange face down on a pallet or wooden platform. Do not store heavy items on top of an expansion joint. Ten year shelf-life can be expected with ideal conditions. If storage must be outdoors joint should be placed on wooden platforms and should not be in contact with the ground. Cover with a tarpaulin.

**Large Joint Handling:** Do not lift with ropes or bars through the bolt holes. If lifting through the bore, use padding or a saddle to distribute the weight. Make sure cables or forklift tires do not contact rubber. Do not let joints sit vertically on the edges of the flanges for any period of time.

**MAINTENANCE:** Periodically inspect the joint for bolt torque, damage, cracking or hardening. The Metrasphere has no serviceable parts.

Note: Some of this information has been taken from the Fluid Sealing Association Handbook on Non-Metallic Expansion Joints.

CUSTOMER _____
PROJECT _____
ENGINEER _____
ARCHITECT _____
PRO. OR P.O. NO. _____



**DESCRIPTION:**

**Spherical Joints**  
Operation, Installation & Maintenance Instructions

DRAWING BY: JC	DATE: 11/24/10	DRAWING NO. Sphere—OIM Rev2
-------------------	-------------------	--------------------------------